


## Installation Guide on AusProof's Cold Shrink Stress Relief Tube

1: Apply the supplied silicone grease to the edge where the insulation screen ends.




2: Fit the cold shrink tube over the cable. The internal stress relief section within the product should overlap the insulation screen by approximately 20mm.

3: Pull the tab to shrink the tube onto the cable.

4: Clean any access grease that was pulled through.

**NOT 20mm**  
from the  
end of the  
product



20mm from the  
internal stress  
relief section.